

INSTALLATION INSTRUCTIONS FOR PDI1346:

- 1) Loosen screws on lower adjustable clamp, and remove bottom two screws.
- 2) Hook the top clamp over the top horizontal rail.
- 3) Lower the assembly until the lower clamp will engage the lower horizontal rail.
- 4) Slide the lower clamp upwards to hook behind and lock into the lower horizontal rail.
- 5) Re-install bottom two screws in the lower clamp.
- 6) Tighten all four screws into the lower clamp to secure the assembly to the horizontal rails.
- 7) Position the PD240-299, mounting block, at the desired installation height.
- 8) Slide the PD240-315, slide stop, up to the bottom of the PD240-299 and tighten the locking bolt to hold the block at the correct height.
- 9) Install PD183-049 stop pins in top and bottom center holes with $\frac{1}{4}$ -20 x $\frac{3}{4}$ hex socket bolts.
- 10) Install arm per arm installation instructions.

