

	MODEL NUMBER: <b>PDI-STM-BP</b>	Document Number: PD196-232R2
	Installation Instructions	Page 1 of 1

## SCOPE:

To install a PDI-STM BACKER PLATE

**NOTES:** Mounting fasteners are customer supplied. The standard fastener requirement is a 1 / 4 - 20 diameter grade 5 or higher fastener. The backer plate has 1 / 4 - 20 threaded inserts.

## TOOL LIST:

1. Safety glasses/goggles
2. Drill
3. Drill bit sized for the chosen mounting fasteners
4. 1" drill bit for coax hole
5. Tools for installation of chosen mounting fasteners

## Bill of Material:

ITEM	Qty.	Part Number	Description
1	1	PDI-STM	Single Table Mount
2	4	PDI-271	Cap Plug RH-20-JN (Cream)
3	4	Bolt	Customer Supplied
4	4	PDI-272	Washer RHW-203
5	1	PDI-STM-BP	Backer Plate

## Safety Steps:

1. Always wear safety glasses/goggles to prevent injury from debris.
2. Follow the installation/removal instructions for your existing products.


## PROCEDURE:

### STEP 1:

Locate and layout the bolt pattern for the mounting fasteners and the coax/cable hole or cutout.

### STEP 2:

Follow the manufacturer's instructions for installation of the chosen mounting fasteners. Drill the fastener holes to the manufacturer's specification. Tighten the fasteners to securely hold the PDI-STM to the mounting surface.



INSERTS MUST FACE AWAY FROM MOUNTING SURFACE

