

### SCOPE:

To install a PDi table stand to an ELED TV. (Your product may vary slightly in appearance from item shown)

#### **PARTS LIST:**

ITEM	QTY	PART NUMBER	DESCRIPTION
1	1	PD133-738	50" STAND FOR LED TV (RIGHT AND LEFT)
2	2	M4 X 14MM	M4X14MM PHILLIPS HEAD MACHINE SCREWS

### **TOOL LIST:**


- 1. Safety glasses/goggles
- 2. Drill and bit for screw.

# **SAFETY STEPS:**

- 1. Always wear safety glasses/goggles to prevent injury from debris.
- 2. Follow the installation/removal instructions for your existing products.
- 3. Only place TV on stable flat surface when using the stand.

# **PROCEDURE**

- 1. Remove table stand and screws from box and protective sleeve.
- 2. Lay TV face down on flat, stable, non scratch surface. Do not lay TV on anything smaller than the bezel of the TV.
- 3. Locate the gray and black metal pieces of the stand labeled with R. Insert the gray metal piece into the black. Secure with (1) M4 x 14mm Philips head screw. Repeat for left hand side.







4. Remove (4) M4 x 30mm long screws from the rear of TV as shown. Keep these screws, as they will be used in the installation of the table stand feet.



M4 x 30mm (supplied with TV)



MODEL NUMBER:		
	PD168-228	

Document Number: PD196-367R1

**ELED Table Stand Installation Instructions** 

Page 2 of 2

5. Insert stands into back of TV on both sides making sure the longer leg is facing the front of the TV as shown.





6. Secure with TV's (4) M4 x 30mm machine screws as shown.

