 PDi Communication Systems, Inc. <i>Better Solutions Are Within Reach®</i>	MODEL NUMBER: PD108-520	Document Number: PD196-446R1
	Smart TV Programming Remote Control	Page 1 of 1

INTRODUCTION

The PD108-520 programming remote provides IR control and setup of PDI's smart television models. It will operate any PDI TV regardless of the TV's Bed A/B/C/D setting. Because this remote has the TV SETUP button to gain full access to the TV's menus, it should not be given to patients. PDI offers other remotes designed for patient use.

Older model TV menus may not respond to the arrow keys. If that happens, use the following key mapping.

VOL+ to move right


VOL- to move left

CH+ to move up

CH- to move down

For TVs built after 2018, a TV firmware update may be available to enable the arrow keys.

MOUSE MODE

The  button toggles between the TV's mouse mode and keyboard mode. Only smart TV's support this function. When the TV is operating in mouse mode the arrow keys will move a mouse cursor, OK key will simulate left mouse click and PAGE UP/DOWN will simulate the mouse wheel.

ANTI-THEFT SCREW

After installing the batteries, an M2 x 5mm flat head screw may be used to secure the battery cover.

Troubleshooting

- Install two high-quality 1.5V "AAA" alkaline batteries. Don't mix old batteries with new batteries.
- The red LED above the POWER key blinks when a code is transmitted.
- Remove batteries when you won't use the remote for a long time. Liquid leakage from old batteries may cause remote failure.
- Make sure there are no objects between the remote control and the TV's sensor that might block the signal.
- Don't place the remote control near a heater or in a damp place. Strong impact to the remote control may cause operational failure.
- Signal from the remote control may be disturbed by sun light or other bright lights. In this case, darken the room or move the TV.

