

	MODEL NUMBER: PD108-210	Document Number: PD196-443R1
	International Patient Remote Control with Bed A/B/C/D	Page 1 of 1

INTRODUCTION

The PD108-210 patient remote provides IR control of PDI televisions. This remote generates control codes in either a Bed A, B, C, or D format to control one of up to 4 televisions in one room.

SET THE TELEVISION BED CODE

If there is more than one television per room, each TV should be set to a unique code-set so that only one remote controls each TV. Use the television's programming remote to set the television to either Bed A, B, C or D. Follow the user instructions provided with the television for this step.

SET THE PATIENT REMOTE BED CODE

Turn the TV On. Aim the remote at the TV and press the remote's **POWER** button. If the TV shuts off, the remote is correctly set for that TV's Bed code. If the TV does not turn off, use the following sequence to set the remote.

Press and hold the **FUNCTION** button while simultaneously pressing and releasing:

- 1 then 2 for bed A
- 2 then 3 for bed B
- 4 then 5 for bed C
- 5 then 6 for bed D

Troubleshooting

- Install two high-quality 1.5V "AA" alkaline batteries. Don't mix old batteries with new batteries.
- Remove batteries when you won't use the remote for a long time. Liquid leakage from old batteries may cause remote failure.
- Make sure there are no objects between the remote control and the TV's sensor that might block the signal.
- Don't place the remote control near a heater or in a damp place. Strong impact to the remote control may cause operational failure.
- Signal from the remote control may be disturbed by sun light or other bright lights. In this case, darken the room or move the TV.

