

PD196-304R3

Page 1 of 1

## SCOPE:

To install a PD181-783 or a PD181-813 rear mount 100mm VESA adapter plate to a PDI-P14 or PDI-P15X television.

#### **PARTS LIST:**

- 1. PDIPPHMSM4X710 PHILLIPS SCREW (4)
- 2. PDIPPHMSM4X716 PHILLIPS SCREW (4)

### **TOOL LIST:**

- 1. Safety glasses/goggles
- 2. Drill and bit for screw.

# **SAFETY STEPS:**

- 1. Always wear safety glasses/goggles to prevent injury from debris.
- 2. Follow the installation/removal instructions for your existing products.

#### PROCEDURE:

- 1. Attach plate to TV with corresponding fasteners as shown. \*See Fig. 1 for direction of plate and Fig. 2 for proper screw position.
- 2. Using M4 X 10 screws, mount TV to existing VESA bracket.
- 3. Make cable connections and check functionality.



